

0011 0012

Polaris

Sauna kit



Dear Customer, congratulations on your purchase of the Polaris sauna kit. Please read the following instructions carefully and follow them to prevent potential damage. We accept no liability for damage resulting from failure to follow these instructions or from improper use.

TABLE OF CONTENTS

Safety instructions 4

Scope of delivery 5-6

Tent setup 7-8

Stove construction 9

Burn-in 10

Sauna operation 11

Stove dismantling 12

Tent dismantling 13

Important Notes 14

TECHNICAL DATA

Article number	0011
Dimensions (assembled)	170 x 170 x 180 cm
Dimensions (folded)	65 x 10 x 10 cm
Weight	5kg

Article number	0012
Dimensions (assembled)	35 x 35 x 20 cm
Dimensions (folded)	35 x 25 x 20 cm
Weight	6kg

SAFETY INSTRUCTIONS

- Always leave the ventilation flap in the tent wall open during sauna operation!
- Extra caution is required in windy conditions. Ensure the sauna tent is securely guyed and firmly anchored.
- Do not operate the sauna unattended.
- Use only suitable and dry firewood.
- Do not place any flammable materials near the stove.
- Do not make any technical modifications to the tent. This can lead to hazards during use and will void the manufacturer's warranty.
- In case of snowfall, support the roof from the inside against the roof load using a suitable ceiling support.
- For safety reasons, dismantle the sauna tent in strong winds.
- Secure the sauna tent with pegs and guy lines. Weigh down the outer edge . Weights (stones or similar) are used to increase the effectiveness of the sauna tent and to prevent drafts under the hem.
- Maintain the minimum distances between the stove and the tent wall.
- Use only suitable infusion agents.
- Children are only allowed in the sauna when accompanied by an adult.

OVERVIEW



Assembled Polaris starter kit

Scope of delivery: Tent



1	Inner tent	6	Instructions
2	Outer tent		
3	Tent bag		
4	Tent pegs & guy lines		
5	Tent poles		

Scope of delivery: Stove



1	Sauna stove	6	Assembly tool
2	Stove connector		
3	Chimney elements		
4	Stove rack		
5	Stove bag		

TENT SETUP

- (1) Place the tent bag on a sufficiently large and level surface.
- (2) Unfold the inner tent (with the pole sleeves).
- (3) Slide the first tent pole through the pole sleeve .
- (4) Slide the second tent pole through the pole sleeve .
- (5) Pull the tent cover towards the tent pole ends to arch the tent.
- (6) Now insert each tent pole end into the metal cotter pins.



TENT SETUP

(7) The basic construction of the inner tent is now complete.
(8) Now pull the outer tent over the inner tent and align it with the inner tent.
(9) Hang the outer tent in metal rings at each corner.
(10) Now secure the tent hem with the pegs.
(11) Attach the guy lines and tension the outer tent.
(12) The tent is set up.



INITIAL STOVE ASSEMBLY

- (1) Remove all elements from the combustion chamber and push the chimney connector upwards through the opening from inside the stove.
- (2) Screw the connector in place from the outside.
- (3) Screw the door handle onto the stove door.
- (4) Place the stove rack in the stove.
- (5) Insert all the fireplace elements into each other.
- (6) The initial stove setup is complete. Now carry out the firing process.



BURN-IN

- Every brand new wood-burning stove must be properly burned in before its first use.
- Place the fully assembled stove (without sauna stones) outside on a safe and level surface (e.g. , a stone floor).
- Open the ventilation slots at the front of the stove door.
- Now, light the stove vigorously and fill the combustion chamber completely with firewood (preferably hardwood such as beech or similar).
- The stove body will begin to glow red-hot when properly burned in. The same applies to the lower chimney elements.
- Operate the stove at full power for at least two hours. Add firewood regularly .
- When heated, production residues such as fats and oils that would otherwise leak inside the tent evaporate.
- After successful initial burning, allow the stove to cool down and only then use it in your sauna tent.



Burn-in process

SAUNA OPERATION

- (1) Position the seasoned sauna heater in the center of the tent, vertically below the chimney opening in the tent roof.
- (2) Slide all the fireplace elements into each other.
- (3) Push the assembled chimney through the opening in the tent roof.
- (4) Open the fresh air vent in the tent wall behind the stove. It provides air for combustion and for breathing.
- (5) The stove is now ready for use.
- (6) Check that the sauna tent is stable. Optionally, weigh down the tent edges with weights (stones, etc.).




STOVE DISASSEMBLY

- (1) After the stove has cooled down , pull the chimney elements apart.
- (2) Remove the ash from the stove and store the fireplace components inside the stove body.
- (3) All elements fit in the stove; do not use force, the chimney pipes could bend.
- (4) Fold in the stove legs.
- (5) Place the stove in the stove bag.
- (6) The stove is now protected and ready for transport.



TENT DISMOUNT

- (1) Remove all tent pegs and tent hem weights.
- (2) Remove the outer tent cover.
- (3) Release the tent poles from the metal pins and carefully slide the inner tent cover towards the center of the tent roof until the tent lies flat on the ground.
- (4) Slide the tent poles through the pole sleeves and remove them.
- (5) Fold and roll the two tent covers together.
- (6) Store all components in the tent bag.



IMPORTANT INSTRUCTIONS

Note : Always keep the ventilation flap open during sauna operation! It supplies the sauna heater and users with the necessary fresh air.

Take down the tent for safety in strong winds.

- Check the condition of the sauna tent and sauna heater before each use.
- Only pack the tent when it is completely dry to avoid mold and cracks.
- Do not use force when setting up or taking down the tent or the stove. The very lightweight and highly functional fabrics could be damaged.
- By adding weight to the outer hem of the tent, the effectiveness of the sauna tent can be increased, as potential drafts under the hem are prevented.
- Do not wash the tent with detergents. Gently scrub stains with water only.
- Avoid strong UV radiation. UV radiation weakens the tent fabric over time. Take down the tent if it will not be used for extended periods, during the summer, or in intense sunlight.
- Leave the sauna if you feel unwell.

MANUFACTURER

Manufacturer:

Alpine Sauna GmbH, Georgsmatt 3b, 6415 Arth, Switzerland
Tel.: +41 44 974 28 05, Email: info@alpine-sauna.com

